CONDURA

NO FROST INVERTER REFRIGERATOR

CNF-223i & CNF-181i





Caution

Please read the following information prior to usage of your refrigerator. Failure to observe these safety guidelines could result in fire, electric shock, injuries, or damages to your refrigerator and/or other property. This operational manual may cover various models and some features described may differ slightly from those found in your refrigerator.



The appliance is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.



Never plug a power cord showing any sign of damage along its length or on both ends. If in doubt, call our customer care hotlines or consult your trusted appliance dealer.



Properly ground your refrigerator while avoiding telephone, electric and/or gas lines. Unplug your refrigerator from the wall outlet before cleaning or performing maintenance work.



Keep all packing materials away from children. Plastic polybags may be used as packaging to protect your refrigerator during transport. Recycle whenever possible.



Use your refrigerator only for keeping food and beverage items in a normal household or similar setting. It is not designed for storing volatile, flammable objects and/or substances. Never attempt to disassemble, repair and/or modify the system for use in a specialised purpose aside from its intended function.



At the end of its useful life, ask your local authorities about the proper disposal procedure for your refrigerator.



This appliance is intended to be used in household and similar applications

Welcome

Thank you for choosing a Condura No Frost Inverter Refrigerator!

To familiarize yourself with all its features, please take some time to read the instructions in this booklet for the proper and safe use of your refrigerator


Please keep this manual for reference and pass it on to any future owners

- Parts and Features
- 2 Start Up
- **3** Temperature Control
- 4 Care and Maintenance
- 5 Safety Information
- **6** Energy Saving Tips
- 7 Storing Fresh Food
- 8 Troubleshooting
- 9 Customer Care



Parts and Features


Here are the reasons why you trust our brand.



| No | Description | CNF-223i | CNF-181i | |
|---|----------------------------------|------------------|------------------|--|
| 1 | Freezer Wind Channel | 1 | 1 | |
| 2 | Freezer Shelf | 1 | 1 | |
| 3 | Freezer Temperature Control | 1 | 1 | |
| 4 | Refrigerator Wind Channel | 1 | 1 | |
| 5 | Refrigerator Temperature Control | 1 | 1 | |
| 6 | Refrigerator Shelf | 2 | 2 | |
| 7 | Crisper Cover | 1 | 1 | |
| 8 | Crisper | 1 | 1 | |
| 9 | Adjustable Bottom Feet | 2 | 2 | |
| 10 | Freezer Door Gasket | 1 | 1 | |
| 11 | Freezer Door | 1 | 1 | |
| 12 | Freezer Door Rack | 2 | 1 | |
| 13 | Refrigerator Door Gasket | 1 | 1 | |
| 14 | Door Switch | 1 | 1 | |
| 15 | Upper Door Rack | 1 | 1 | |
| 16 | Lower Door Rack | 1 | 1 | |
| 17 | Refrigerator Door | 1 | 1 | |
| Gross Storage Volume (Liters / cu.ft.) | | 222 (8.0) | 181 (6.4) | |
| Total Storage Volume (Liters / cu.ft.) | | 205 (7.2) | 168 (6.0) | |
| Freezer Volume (Liters) | | 52 (1.8) | 37 (1.3) | |
| Ref Volume (Liters) | | 153 (5.4) | 131 (4.6) | |
| Unit Dimension with Handle (W x D x H) mm | | 550 x 562 x 1456 | 475 x 557 x 1440 | |
| Voltage (V | /) / Cycle (Hz) | 230 / 60 | 230 / 60 | |
| Defrosting System | | Automatic | Automatic | |



Place refrigerator on a firm & flat surface, away from direct sunlight & heat sources (like an oven or stove).



CAUTION or WARNING:

Install the unit in a well ventilated location.


Leave at least two inches of space between ref and wall, and 12 inches of space between ref and ceiling or overhead cabinet.


Let the motor oil settle down for three to four hours before plugging your Refrigerator.

Plug your refrigerator directly to a 230V wall outlet. Avoid using extension cord.

Set both control knob to NORMAL. Allow your refrigerator to cool for four (4) hours before loading food and beverage items.


Adjust the temperature to the appropriate setting for efficient cooling performance. See temperature control section for more information.






DO NOT USE EXTENSION CORD.

Your **Condura NO FROST Inverter Refrigerator** has two control knobs. Adjusting the temperature control setting in the refrigerator compartment affects the temperature in both the freezer and refrigerator section.



Freezer Temperature Control

Refrigerator Temperature Control





Importante Note:

For stable cooling performance, set the control knob to MID for freezer and ref section.

Proper temperature management is essential for the optimal performance of your refrigerator. It is recommended to adjust the temperature based on the amount of food and beverage items stored in your refrigerator:

| TEMPERATURE CONTROL SETTING | | | | |
|---|-----------------|-------------|---|--|
| OPTIMUM | Freezer Section | Ref Section | | |
| Cooling Performance Setting Freezer MID Ref Section MID Note: Recommend to set both knob to mid to ensure stable performance. | COLD COLDER | OCLD COLDER | Recommended to use for moderate amount of load. | |
| Minimum Cooling Performance Settling Freezer COLD Ref Section 2 - 4 | COLD COLDER | NO COMPA | Recommended to use for minimal amount of load. | |
| Maximum Cooling Performance Setting Freezer COLD Ref Section 7 | COLDCOLDER | OLD OLDER | Recommended to use for full amount of load. | |

Be mindful not to obstruct the air vents found at the rear of the freezer and fridge compartments to ensure free air circulation. Adequate spacing of stored food and beverage items will also ensure the circulation of cool air.

Defrosting

Do not use mechanical devices or other means to accelerate the defrosting process.

REFRIGERATOR CLEANING

Proper use of your No Frost Refrigerator Inverter ensures that it functions at an optimal level. Regularly cleaning your refrigerator will keep it in top working condition.

UNPLUG your Condura NoFrost Inverter Refrigerator. Remove all contents, including racks and shelves.

CLEAN the racks, shelves, gasket, interior and exterior of your refrigerator using a clean damp cloth. Wipe it dry.

PLUG your refrigerator directly to a 230V wall outlet. Set the control knob to NORMAL and allow your refrigerator to cool for four(4) hours before loading food and beverage items.

WARNING – Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer [IEC 60335-2-24]



USING THE LEVELLERS

It is important to keep your refrigerator standing firm on a level surface to eliminate vibration and unnecessary noises during operation. Adjust the levellers found in both sides of your refrigerator to ensure its stability.

LED LIGHT REPLACEMENT

It is recommended to have our service technicians to do the light replacement. Call our customer care hotlines for further assistance.



This is to prevent unpleasant odour build-up in your refrigerator.





Call our customer care hotline or any authorised service center immediately for repair or replacement of exposed or damaged power cord.

When touching or cleaning the plug, make sure your hands are dry.

When unplugging, always grip the plug firmly and do not yank the power cord out of the wall socket.

Ensure that the power cord is not bent excessively or pressed down by a heavy object. Do not plug refrigerator in loose sockets.

The plug's tip should be cleaned regularly with a dry cloth; otherwise, it may cause fire.

DO NOT USE EXTENSION CORD

USAGE & STORAGE

Use your refrigerator only for the storage of food and beverage items.

Storing hazardous materials such as ether and benzyne can cause an explosion.

Do not store store vaccines, heat-sensitive medicine and scientific materials etc. This may require precise temperature.

It is recommended that you only store bottled drinks in the refrigerator compartment.


If not to be used for a long time, refrigerator should be unplugged. A possible problem in power cable may cause fire

WARRANTY

Only accredited service technicians are authorised to repair this product. If you suspect it is damaged, or if it malfunctions, please see the troubleshooting section.Do not attempt to disassemble, repair nor modify your refrigerator as this may render your warranty void.

DISPOSAL

Recycle when possible. Contact your local authorities for the proper disposal of your refrigerator as it contains flammable gas that require special disposal procedures.



POWER CORD



USAGE & STORAGE


WARNING: Your Inverter No Frost's cooling system contains R600a refrigerant.

The gas is flammable. Therefore, pay attention to not damaging the cooling system and piping during usage and transporatation. In the event of damage, keep your product away from potential fire sources that can cause the product catch a fire and ventilate the room in which the unit is places.


CAUTION or WARNING:

- Donot let children and lack of experience and knowledge to play or operate the appliance.
- Do not use sharp objects or tools that may cause damage to the refrigerant circuit
- Do not use electrical appliances inside the food storage compartments of the appliance.

Allow warm food or hot beverages to cool down to room temperature before storing it in your refrigerator. Put frozen food and beverage items in the fridge compartments to thaw.



Do not keep the ref or freezer door open for too long when putting in or taking out food or beverage items.



Wash and rinse fruits and vegetables to prolong freshness. Dry before storing in the crisper pan.



A large amount or load of stored food and beverage items will lower the cooling efficiency of your refrigerator. On the other hand, minimizing unnecessary opening of doors will help the unit to function efficiently.



| PROBLEM | CHECK IF |
|---|---|
| Refrigerator would not | Power plug is properly connected to a wall outlet. |
| turn on or is not | rower plug is properly confineded to a wall outlet. |
| working at all. | Refrigerator light turns on when the fridge door is left open. |
| Temperature is not cold enough or refrigerator | Refrigerator has adequate clearance from the wall. (Please see start up section for more information) |
| is not cooling. | Freezer and fridge doors are tightly shut. |
| | Air vents are not blocked. (Please see storing fresh food section for more information) |
| | Food and beverage items are spaced enough to allow adequate air circulation. (Please see storing fresh food section for more information) |
| | Temperature setting is properly adjusted according to refrigerator load. (Please see temperature control section for more information) |
| Refrigerator emits a foul odor. | There is no spoiled food or beverage item inside. |
| foul odor. | Strong smelling food items are properly sealed. (Please see storing fresh food section for more information) |
| | There is no excessive accumulated defrost water in drain pan. (Please see care and maintenance section for more information) |
| | Refrigerator is thoroughly cleaned. (Please see care and maintenance section for more information) |
| There is sweating in the | Temperature is properly set. (Please see temperature control section for more information) |
| exterior ref cabinet, particularly during cold | Freezer and fridge doors are tightly shut. |
| weather. | Sweat looks like condensation on the window of an air-conditioned room on a rainy day. This is normal. |
| Refrigerator makes unusual noises. | Refrigerator is installed on a stable, level surface. (Please see start up section for more information) |
| | Note that noise may also come from normal operation: Refrigerant passing through the system may make sizzling sounds. Thermostat control turning on and off will make ticking sounds. Compressor will make a humming sound. |

If problem still occurs after checking all items above, please call our "

Customer Care Hotlines ": Trunkline: <u>02 8 863 5555</u> TOLL FREE: <u>1800 10 888 8888</u> Globe: <u>+63 917 536 3030</u> Smart: +63 947 996 2415

*Numbers are subject to change without prior notice Please prepare the following information to be relayed to the Customer Care Representative who will take your call:

- Customer ID No (if already previously assigned one)
- Customer Name
- Address (House No., Block / Lot, Street, Subdivision, Barangay, City and Nearest Landmarks)
- Model & Serial No of your refrigerator (found on the sticker inside ref)
- Dealer Branch (where the unit was purchased)
- Date of purchase (according to sales invoice / receipt)
- Complaint or problem encounter

You may also scan the provided QR code to book a service



Scan QR code for service needs



CONDURA HOME

Products that let you experience the Condura brand offering, providing solutions to your home needs according to your chosen lifestyle. (No Frost Prima, Maxima and Ultima Refrigerators, Personal Refrigerators)



CONDURA HOME & BUSINESS

Products that are made durable and efficient for business use, which are even better for home use. (Negosyo Inverter PRO, Negosyo Inverter Style, Negosyo Style, No Frost Optima)



CONDURA COMMERCIAL

Products that come with Negosyo Features, so you can go about your business without worrying about performance and service. (Upright Freezers, Chest Freezers, Beverage Coolers)



CONCEPCION DURABLES INCORPORATED

www.facebook.com/ConduraPhilippines

CONCEPCION DURABLES INCORPORATED

Trunk Line 02 8 863 5555 Globe 0917 536 3030 Smart 0947 996 2415

CUSTOMER SERVICE DEPARTMENT

GMA & LUZON Area

Address: 308 Sen. Gil Puyat Avenue, Makati City

Trunk Line: 02 8 863 5555

TOLL FREE: 1800 10 888 8888

Mobile Number: +63 917 536 3030 (Globe) "SMS Only" +63 947 996 2415 (Smart) "SMS Only"

Covered Region/Areas: National Capital Region (NCR), Ilocos Region (Region I), Cordillera Administrative

Region (CAR), Central Luzon (Region III), CALABARZON (Region IV-A),

MIMAROPA except Romblon (Region IV-B), Bicol Region except Masbate (Region V)

Email Address: customercare@condura.com

CEBU Regional Office

Address: Dr. A Esperanza Building, A.C Cortes Ave. Mandaue City

Telefax No: 032 328 1416 / 032 347 3380

Mobile Number: +63 947 996 2416 +63 921 222 0942 TOLL FREE: 1800 10 888 8888

Covered Region/Area: Masbate, Central Visayas (Region VII), Eastern Visayas (Region VIII)

ILOILO Regional Office

Address: 109 Yulo Street, Brgy. Yulo-Arroyo, Iloilo City, Iloilo

Telefax No: 033 336 1121

Mobile Number: +63 947 996 2417
+63 999 925 5736

TOLL FREE: 1800 10 888 8888

Covered Region/Area: Romblon, Western Visayas (Region VI)

CAGAYAN DE ORO Regional Office

Address: No. 102 CKY Center, Capistrano-Chavez Street, CDO City

Telefax No: 088 881 0615
Mobile Number: +63 947 996 2419
+63 939 253 5011
TOLL FREE: 1800 10 888 8888

Covered Region/Area: Zamboanga Peninsula (Region IX), Northern Mindanao (Region X), Autonomous Region

in Muslim Mindanao (ARMM) except Maguindanao, Agusan del Norte,

Surigao del Norte

DAVAO Regional Office

Address: 1C, Nand-Saling Building, Sobrecarey Street, Obrero, Davao City

Telefax No: 082 291 7276 Mobile Number: +63 947 996 2418 +63 922 294 1478

TOLL FREE: 1800 10 888 8888

Covered Region/Area: Davao Region (Region XI), SOCCSKSARGEN (Region XII), Agusan del Sur, Surigao del Sur,

Maguindanao

*All contact information detailed above may change without prior notice.

>{

CONCEPCION DURABLES INCORPORATED CUSTOMER SERVICE DEPARTMENT

308 Sen. Gil Puyat Avenue, Makati City


 Trunk Line
 02 8 863 5555

 Globe
 0917 536 3030

 Smart
 0947 996 2415

PO BOX 211 COMMERCIAL CENTER
MAKATI CITY

BUSINESS REPLY! Permit No. 2416A! NO STAMP NEEDED





PRODUCT WARRANTY CERTIFICATE

IMPORTANT: PLEASE READ CAREFULLY

Concepcion Durables, Inc. (CDI) warrants the purchaser that this CONDURA NO FROST INVERTER REFRIGERATOR will be free from defective material and workmanship and agrees to repair or, at its discretion, replace any defective material with a new or equivalent part through any of its Authorised Service Centers only if found to be manufacturer's defect and in accordance with the terms of this warranty, subject to the following conditions:

1. COVERAGE OF WARRANTY

The Condura No Frost Inverter Warranty is applied to Refrigerators used for household purposes only.

| 2 | WARRANTY | PERIOD | (from | the | data | of. | original | nurchase) |
|---|----------|--------|-------|-----|------|-----|----------|-----------|
| | | | | | | | | |

CONDURA WARRANTY INVERTER BOARD 2 years..... 1 year..... SYSTEM PARTS & LABOR (Refrigerant, Filter Drier, Motor Relay Fan Motor, & LFD Lamp) COMPRESSOR (Motor only, EXCLUDES system 10 years..... parts & labor) NO WARRANTY..... Glass Shelves, Crisper Glass Cover, Power Cord,

Plastic Parts (bottle racks, crisper pan & rubber gasket)

There will be corresponding charges for labor and replacement parts after the warranty period.

3. LIMITATIONS

This warranty is not transferable, valid only in the Philippines, and does not apply to damage(s) due to fire. improper use or punctured, force majeure (typhoon, flood, lightning, earthquake, etc.), use with voltage beyond the allowable range of 198V to 242V, or failure to follow operating instructions provided in the manual. If the serial number is removed or defaced, or if the unit has been tampered with, altered or in any way repaired, serviced, or worked on by anyone other than a duly authorized representative or Service Center, this warranty is considered null and void. CDI offers this warranty as the only remedy available to the original purchaser for any defect that may arise within the warranty period. Correction of defects shall be considered as complete fulfillment of liabilities and responsibilities of CDI to the original purchaser. In no event shall CDI be held responsible for any damage or consequence that may arise as a result of using this Condura product.

| MODEL NO. | | SERIAL NO. | | |
|-----------|---|---|--|--|
| NOTE: | Keep this warranty card together with your Origin If the date of purchase cannot be proven, warra | nal Sales Invoice/Official Receipt as proof of purchase. nty shall be based on CDI's Invoice to Dealer. | | |



| Fill out this warranty card completely and mail wi from date of purchase. This will activate your wa | |
|---|--|
| MODEL NO. | SERIAL NO |
| DEALER (Please indicate branch) | |
| DATE OF PURCHASE | DEALER INVOICE NO |
| CUSTOMER NAME | EMAIL ADDRESS |
| ADDRESS | |
| TELEPHONE NO. | MOBILE NO |
| | y Concepcion Durables, Inc. (CDI) of the data above for the lished in its website (www.condura.com), which is deemed |



www.condura.com