CONDURA

NEGOSYO UPRIGHT FREEZER INVERTER PRO

CUF800MNi-a & CUF1000MNi-a





TABLE OF CONTENTS


•	PRODUCT SPECIFICATION AND FEATURES	I
•	INSTALLATION	2
•	START-UP OPERATION	3
•	FOOD STORAGE TIPS	3-4
•	TEMPERATURE CONTROL SETTING	5
•	WHEN AND HOW TO DEFROST	6
•	CLEANING, CARE & MAINTENANCE	6
•	SAFETY INSTRUCTIONS	7
•	COMPRESSOR SOUND	8
•	ENERGY SAVING TIPS	8


Thank you very much for buying CONDURA Freezer.

Before using your CONDURA Freezer,

Please read this operational manual to ensure the correct & effective use of your appliance.

PRODUCT SPECIFICATION AND FEATURES





	CUF800MNi-a	CUF1000MNi-a
Gross Volume (Liters)	228	284
Net Volume (Liters)	220	256
Over-all Height (mm)	1506	1703
Over-all Depth (mm)	660	660
Over-all Width (mm)	540	540
Voltage / Cycle	230 / 60	230 / 60
Defrosting System	Manual	Manual
Ice Scraper	1	1
Utility Pan	1	1
Adjustable Leveler	2	2
Platform	No	No
Foamed-in-place Insulation	Yes	Yes
Hot Gas Tube System	Yes	Yes
Power Input (W)	91.0	98.9
Energy Consumption (kWh/24h)	0.84	0.94

Note: Product Specification and Features are subject to change without prior notice.

INSTALLATION


Follow these instructions before operating your freezer:

- Freezer should not be exposed to direct sunlight or any heat source. Heat causes the compressor to work harder.
- 2. Provide adequate air circulation. Allow at least 2 inches clearance between the wall and the condenser, and a minimum of 12 inches clearance above the freezer.
- 3. Your freezer best operates on 230 volts power supply. If your area is experiencing severe voltage fluctuations (below 198 or over 242 volts), it is advisable to use an Automatic Voltage Regulator (AVR).
- 4. To avoid power overload, plug the service cord directly into a wall outlet. Do not use extension cord.
- For safety reason, it is advisable to ground the unit by connecting the ground wire provided to a metal water pipe line.
- 6. To compensate floor unevenness, adjust clockwise or counterclockwise the leveler located on the lower front corners of your freezer. It is recommended that the unit be slightly tilted backward to allow defrost water to flow inward during defrosting.


CAUTION or WARNING:


Install the unit in a well ventilated location.














* Image may vary from Actual Unit

START-UP OPERATION

Caution: For newly delivered unit, please wait for at least 4 hours before plugging to a power supply to allow oil in the system to settle.

- Plug the service cord into the wall outlet.
 Do not use extension cord.
- 2. Set temperature control at No. 3 setting without any load. The temperature control is located at the back of the cabinet.
- 3. Load your food after 4 hours. In doing so, please observe the following rules:
 - Don't touch the freezer compartment with damp hands,
 - Don't place hot food inside the freezer. Let the food cool out before storing it inside.
 - Don't overload your freezer. Maximum allowable new load is 2 kg per layer for best freezing performance. Additional food may be stored inside once the initial load is already frozen. For additional information, please see "Food Storage Tips".

FOOD STORAGE TIPS

- 1. Freezer only high quality meat, fish, vegetables and fruits. The freezer will not improve the quality of the meat and fish, nor compensate for under ripe or over ripe fruits and vegetables.
- 2. Before freezing, refrigerate fruits and vegetables. For flavor and least vitamin loss, freeze them on the day they are picked.
- 3. Label packages. Place food type, date, and no. of servings or weight. Keep a running inventory of freezer contents. Use good materials and airtight packaging techniques.

- 4. For optimal feezing, arrange food packages in a single layer.
- 5. Rotate food, observe "First in, First out" to maintain food quality.
- Keep food frozen until you are ready to use them. DO NOT REFREEZE THAWED FOOD.

Food not recommended for freezing:

Boiled Potatoes
Salad Greens (lettuce, celery, etc)
Cooked Egg White
Meringues, Cake Icing, Butters
Milk Sauces, Mayonnaise, Gravy
Cooked Shellfish
Broiled Meat / Fish
Cured Meats (Tocino, Hotdogs, Bologna)
Meat Stuffing, Fried Food
Jelly / Gelatin, Salt / Spices


Suggested storage life at frozen condition (-18°C) or colder are as follows:

Meat 6-8 months Fish 12 months

TEMPERATURE CONTROL SETTING

The temperature in your upright freezer is set by using the control knob. The numbers on the control knob do not represent the actual temperature.


Setting No. "5" represents the coldest temperature




Recommended Setting for Temperature Control Knob

Note: Kindly rotate the control knob into clockwise to set the knob into desired setting.


Setting No. "3-4" - for storing "HALF-FULL LOAD"



Setting no. "1-2" - for storing "MINIMAL" load



Setting No. "5/Coldest" - "FULL" load. Provide spaces in-between food stuff to let cold air circulate for best freezing performance.



WHEN AND HOW TO DEFROST

Defrost your freezer when ice accumulation reaches ½ inch thick in the freezer layers. Thick ice formations insulate the freezer, thus lowering the cooling capabilities of your freezer.

How to Defrost

- Set the temperature control at "OFF" position. Unplug the service cord from the wall outlet.
- Remove frozen food from the freezer. If food stuff sticks to the freezer layers, you may use the Ice scraper or wait for the ice to melt
- 3. To facilitate fast defrosting, leave the door open.
- 4. Use the utility pan to collect the defrost water.
- 5. Wipe, clean and dry the interior and exterior of the freezer. Refer to "Cleaning, Care and Maintenance" for instructions.
- 6. Repeat Start-up operation.

CAUTION or WARNING:

Do not use mechanical devices or other means to accelerate the defrosting process

CLEANING, CARE AND MAINTENANCE

- 1. It is important to keep your freezer clean to prevent odors. Wipe spillage immediately to avoid, stain surfaces which may cause corrosion.
- 2. Avoid scratching the evaporator. Dont use metallic tools, scouring pads, brushes, and abrasive cleaners or strong alkaline solutions. These may damage the superficial coating of the coils. Use soft cloth with lukewarm water.
- 3. Wash door gasket with mild soap and lukewarm water. Rinse well and dry.
- 4. Dust the condenser and compressor at least twice a year for maximum operating efficiency. Always unplug the unit before dusting.



SAFETY INSTRUCTIONS

- Do not use defective or wornout power cord. For your safety, do not try to repair or replace defective power cord. Contact the authorize service center nearest you.
- Your freezer is packed with plastic polybag to protect the appliance during transport.
 Keep all packaging materials away from children.
- When disposing your old freezer, remove the door gasket to avoid children from being trap inside.
- Do not dispose your freezer near open flame.



Only Qualified Technician Should Repair





CAUTION or WARNING:

- Do not let the children and lack of experience and knowledge to play or operate the appliance.
- Do not use sharp objects or tools that may cause damage to the refrigerant circuit.
- Do not use electrical appliances inside the food storage compartments of the appliance.
- Do not use extension cord.

If problem still occurs after checking all items above, please call our *Customer Care Hotlines:

 Trunkline:
 02 8 863 5555

 TOLL FREE:
 1800 10 888 8888

 Globe:
 +63 917 536 3030

 Smart:
 +63 947 996 2415

*Number are subject to the change without prior notice

Please prepare the following information to be relayed to the Customer Care Representative who will take your call:

- Customer ID No. (if already previously assigned one)
- Customer Name
- Address (House No., Block / Lot, Street, Subdivision, Barangay, Clty and Nearest Landmarks)
- Contact Nos. (Land line Nos. House & Office, Cellphone Nos.)
- Model & Serial No. of your refrigerator (found on the sticker inside ref)
- Dealer Branch (where the unit was purchased)
- Date of Purchase (according to sales invoice/receipt)
- Complaint or problem encountered

You may also scan the provided QR code to book a service



Scan QR code for service needs

COMPRESSOR SOUND

- Refrigerators are operated with compressors which emit sounds. The sound level of your unit depends on its position, usage and unit age.
- Under normal operating condition, the refrigerant flow of the compressor can be heard. This however has no effect on the performance of your freezer.
- The compressor's sound emission may be louder on the initial operation of your freezer. However, this will gradually reduce.
- Place your freezer on leveled solid ground to avoid unusual noise caused by uneven positioning.

ENERGY SAVING TIPS

- Check your freezer if there is sufficient ventilation which means there
 is adequate spacing between the walls and the unit
- Set thermostat from higher to lower settings as soon as possible (depends on how loaded your unit is).
- Before loading the appliance with food, make sure they are cooled to ambient temperature.
- Your freezer should not touch the wall or kitchen units standing next to it.
- Ice and frost layer increase energy consumption, make sure you defrost regularly.
- If the door gasket is damaged or if the sealing is poor, contact authorize service center to possible adjustment or replacement.

Fill-up this warranty card completely and mail within 15 days from date of purchase. This will activate your three (3) years warranty that is VALID FOR NEGOSYO LISE Only from **Condural**



MODEL NO.: DEALER: DATE OF PURCHASE:	SERIAL NO.: BRANCH: DEALER INVOICE NO.:	
CUSTOMER NAME: ADDRESS: TELEPHONE NO.:	MOBILE NO.:	
□ I consent to the collection, processing and use by C for the purposes identified in its Data Privacy Notice p deemed incorporated into this Warranty Card.	Concepcion Durables, Inc. (CDI) of the data above	



CONDURA

PRODUCT WARRANTY CERTIFICATE

IMPORTANT: PLEASE READ CAREFULLY

Concepcion Durables, Inc. (CDI) warrants the purchaser, that this CONDURA refrigerator will be free from defective material and workmanship, and agrees to repair, or at its discretion, replace any defective material with a new or equivalent part, through any of its Authorized Service Centers, only if found to be manufacturer's defect and in accordance with the terms of this warranty, subject to the following conditions:

1. WARRANTY PERIOD (from the date of original purchase)

CONDUKA	WARRANTI		
1 year	 INVERTER BOARD		
3 years	 SYSTEM PARTS & LABOR (Refrigerant, Filter Drier,		
	Condenser Coil, Rollbonds & Thermostat)		
10 years	 COMPRESSOR (Motor only. Does NOT include System		
	Parts & Labor)		
3 months	 PLASTIC PARTS (Uitilty Pan & Rubber Gasket)		
NO Warranty	 Cover Pan Freezer & Line Cord		

WADDANITY

There will be corresponding charges for labor and replacement parts after the warranty period.

2. COVERAGE OF WARRANTY

The CONDURA warranty is also applied to refrigerators used for business and commercial purposes.

3. LIMITATIONS

This warranty is not transferable, valid only in the Philippines, and does not apply to damage(s) due to fire, improper use or abuse (punctured), force majeure (typhoon, flood, lightning, earthquake, etc.), use with voltages beyond the allowable range of 198V to 242V, or failure to follow operating instructions, provided in the manual, if the serial number is removed or defaced, or if the unit has been tampered with, altered or in any way repaired, serviced or worked on by anyone other than a duly authorized representative or Service Center, this warranty is cosidered null and void. Concepcion Durables, Inc. (CDI) offers this warranty as the only remedy available to the original purchaser for any defect, that may arise within the warranty period. Correction of defects shall be considered as complete fulfillment of liabilities and responsibilities of CDI to the original purchaser. In no event shall CDI be held liable for any damage or consequence that may arise as a result of using this CONDURA product.

MODEL NUMBER:	NUMBER:	SERIAL NUMBER:	

NOTE: Keep this warranty card together with your Original Sales Invoice / Official Receipt as proof of purchase. If the date of purchase cannot be proven, warranty shall be based on CDI's invoice to Dealer.

CONCEPCION DURABLES INCORPORATED CUSTOMER SERVICE DEPARTMENT

308 Sen. Gil. Puyat Avenue, Makati City Trunk Line: 02 8 863 5555 TOLL FREE: 1800 10 888 8888

Mobile Nos.: 0917 536 3030 (GLOBE)

0947 996 2415 (Smart)

PO BOX 211 COMMERCIAL CENTER

MAKATI CITY







CUSTOMER SERVICE DEPARTMENT

GMA & LUZON Area

Address: 308 Sen. Gil Puyat Avenue, Makati City

Trunk Line: 02 8 863 5555 TOLL FREE: 1800 10 888 8888

Mobile Number: +63 917 536 3030 (Globe) "SMS Only" +63 947 996 2415 (Smart) "SMS Only"

Covered Region/Areas: National Capital Region (NCR), Ilocos Region (Region I), Cordillera Administrative Region

(CAR), Central Luzon (Region III), CALABARZON (Region IV-A), MIMAROPA except

Romblon (Region IV-B), Bicol Region except Masbate (Region V)

Email Address: customercare@condura.com

CEBU Regional Office:

Address: Dr. A Esperanza Building. A.C Cortes Ave. Mandaue City

Telefax No: 032 328 1416 / 032 347 3380

Mobile Number: +63 947 996 2416 +63 921 222 0942

+63 921 222 0942 TOLL FREE: 1800 10 888 8888

Covered Region/Area: Masbate, Central Visayas (Region VII), Eastern Visayas (Region VIII)

ILOILO Regional Office:

Address: 109 Yulo Street, Brgy. Yulo-Arroyo, Iloilo City, Iloilo

Telefax No: 032 336 1121 Mobile Number: +63 947 996 2417 +63 999 925 5736

TOLL FREE: 1800 10 888 8888

Covered Region/Area: Romblon, Western Visayas (Region VI)

CAGAYAN DE ORO Regional Office:

Address: No. 102 CKY Center, Capistrano-Chavez Street, CDO City

Telefax No: 088 881 0415 Mobile Number: +63 947 996 2419 +63 939 253 5011 TOLL FREE: 1800 10 888 8888

Covered Region/Area: Zamboanga Peninsula (Region IX), Northern Mindanao (Region X), Autonomous Region in

Muslim Mindanao (ARMM) except Maguindanao, Agusan del Norte, Surigao del Norte

DAVAO Regional Office:

Address: 1C, Nand-Saling Building, Sobrecarey Street, Obrero, Davao City

Telefax No: 082 291 7276
Mobile Number: +63 947 996 2418
+63 922 294 1478
TOLL FREE: 1800 10 888 8888

Covered Region/Area: Davao Region (Region XII), SOCCSKSARGEN (Region XII), Agusan del Sur, Surigao del Sur,

Maguindanao

^{*}All contact information detailed above may change without prior notice.