CONDURA

NEGOSYO INVERTER PRO REFRIGERATOR

CSD73SAi, CTD75MNi, CTD85MNi, CTD93MNi, CTD102MNi





Table of Contents

Start Up & How to control temperature?
2 How to clean & defrost? 9-10
3 Safety - Do's & Don'ts
Energy - How to save money?

How to keep food fresh?	6
Troubleshooting (before calling customer service)	8
Parts List	0



Start Up & How to control temperature?


Maximize refrigerator performance and energy efficiency. Read on and find out how.

1A. START UP

 Place refrigerator on a firm & flat surface; and away from direct sunlight & heat sources (like oven or stove).




Leave at least 2 inches of space between ref and wall; and 12 inches of space between ref and ceiling or overhead cabinet.




For safety reason, it is advisable to ground the unit by connecting the ground wire provided at the back of the unit.

Do not connect the grounding wire to any gas pipes or phones lines.




- 4. Let the motor oil settle down for 3-4 hours before plugging-in the refrigerator.
- 5. Plug the refrigerator directly to a wall outlet (230V).

Do not use extension cord.



- 6. Allow the refrigerator to cool for 3 HOURS BEFORE LOADING FOOD & BEVERAGE ITEMS. Pre-cool with the temperature control knob set at: "3" settings.
- 7. Turn the temperature control knob to the appropriate setting after loading. Please refer to item 1B & 1C., page 5 & 7 for proper settings.



8. To compensate for floor unevenness, adjust clockwise or counter clockwise the leveller located on the lower front corners of your refrigerator. It is recommended that the unit be slightly tilted backward to allow defrosting water to flow inward during defrosting.

CAUTION or WARNING:


Install the unit in a well ventilated location.

1B. HOW TO CONTROL TEMPERATURE BASED ON REFRIGERATOR CONTENTS

FOR TWO DOOR MODELS:


Setting 1-2: For storing MINIMAL amount of food/drinks. Setting 3-4: For storing MODERATE amount of food/drinks.

Setting 5: For storing LARGE amount of food/drinks & for faster freezing.



When freezing ice bags:

Arrange ice bags properly for faster freezing. Temperature control knob must be set at "5".




1C. HOW TO CONTROL TEMPERATURE BASED ON FOOD PLACED IN REF

FOR SINGLE DOOR MODELS:

Setting 1-2: For storing MINIMAL amount of food/drinks.


Setting 3-4: For storing MODERATE amount of food/drinks.

Setting 5: COLDEST for storing LARGE amount of food/drinks & faster freezing.



When freezing ice bags:

Arrange ice bags properly for faster freezing. Temperature control knob must be set at "coldest"



2

How to clean & defrost?

Proper maintenance is essential in saving electricity. Just follow these easy steps in cleaning and defrosting your ref.


2. DEFROSTING & CLEANING

Defrosting is necessary when ice formation is already 1/2 inch thick.

Two-Door Models (Manual Defrost)

- Step 1 Set the temperature control knob to "OFF" then unplug refrigerator.
- Step 2 Remove ref contents including racks and shelves.
- Step 3 Leave the freezer and ref door open until ice has melted. You may also use the ice scraper provided.
- Step 4 Clean inner walls of the ref and freezer with damp cloth.
- Step 5 Wipe rubber gasket, ref & freezer doors and cabinet with cloth.
- Step 6 Empty and clean drain pan.
- Step 7 Plug refrigerator. Set temperature control knob to "3" setting.
- Step 8 Return food and beverage items after 1 hour.

 Re-Adjust temperature control knob to its proper setting based on ref contents.





Single-Door Models (Semi-Automatic Defrost)

- Step 1: WITHOUT turning off the temperature control knob and unplugging the ref, press the ONE TOUCH DEFROST BUTTON.
- Step 2: Remove ref contents including racks and shelves (for washing) EXCEPT the "CHILL TRAY".
- Step 3: (Optional) Leave freezer door and ref door open until ice has melted.
- Step 4: Clean inner walls of the ref and freezer with damp cloth.
- Step 5: Wipe rubber gasket, ref and freezer door and cabinet with dry cloth.
- Step 6: Empty and clean chiller.
- Step 7: Set temperature control knob to "3" setting. Ref automatically turns on when the defrost button pops up.
- Step 8: Return food and beverage items after 1 hour.

 Re-Adjust temperature control knob to its proper setting based on ref contents.

CAUTION or WARNING:

Do not use mechanical devices or other means to accelerate the defrosting process.



Safety


- Do's & Don'ts

Better SAFE than SORRY.


3. SAFETY

A) POWERCORD

- Call Customer Care Hotline or any authorized service center immediately for repair or replacement of exposed and damaged power cord.
- 2. When touching or cleaning the plug, make sure your hands and rug are dry.
- 3. When unplugging, always grip the plug firmly and do not yank the power cord.



- 4. Do not plug refrigerator in loose sockets.
- 5. Ensure that the power cord is not bent excessively or pressed down by a heavy object.




6. Do not use extension cord.

B) STORAGE

- Storing hazardous materials, such as ether and benzyne, can cause an explosion.
- 2. Do NOT store bottled drinks in the freezer.

C) HANDLING

- Call customer care hotline or any authorized service center immediately if problem/s are encountered. Do not attempt to disassemble or repair refrigerator.
- 2. Do not touch the freezer's inner wall with wet hands to avoid frost bite.
- Avoid water contact in areas near the temperature control knob to prevent shock hazards.



D) DISPOSAL

Please contact local authorities for the proper disposal of your refrigerator. The gas in the insulation material requires special disposal procedure.

CAUTION or WARNING:


- Do not let the children and lack of experience and knowledge to play or operate the appliance.
- Do not use sharp objects or tools that may cause damage to the refrigerant circuit.
- Do not use electrical appliances inside the food storage compartments of the appliance.
- 4. The LED Light must not be replaced by user! If the LED Light is damaged, it is highly recommended to have our authorized service personnel to do the replacement for you.



Earn more and save more.


4. ENERGY SAVING TIPS

1. Cool down hot food items first before placing inside the refrigerator.



- 3. Properly adjust temperature setting according to refrigerator load.
- 4. Defrost and clean refrigerator regularly.

2. Do not keep the ref or freezer door open for too long when putting in or taking out food or beverages.



(5)

How to keep food fresh?

Keep food fresh for your business and home.

5. KEEPING FOOD FRESH


1. Cool down hot food items first before placing inside the refrigerator.




3. Cover food containers with lid, cling wrap or plastic bag.



2. Dry fruits and vegetables before storing in the refrigerator.



4. Store vegetables in the crisper pan.





Troubleshooting

Things to check before calling customer service or any of the authorized service centers.

6. TROUBLE SHOOTING GUIDE (BEFORE CALLING CUSTOMER SERVICE)

PROBLEMS ENCOUNTERED	CHECK IF
When refrigerator would not turn ON:	The power cord is properly plugged. The temperature control knob is in "OFF" position.
2. When refrigerator is not cooling:	The temperature control knob is set according to refrigerator load. The refrigerator & freezer doors are tightly shut. The lamp turns off while the ref door is being closed.
3. When the refrigerator emits foul odor:	1. There is spoiled food or drink inside the refrigerator. 2. The drain pan is free of accumulated water. 3. The refrigerator is thoroughly cleaned after defrosting.
When there is dew or moisture in the vegetable compartment:	1. The ref door is tightly shut. 2. The crisper pan is properly installed and not pushed all the way back.
When there is sweating in the exterior ref cabinet during cold weather:	1. The temperature control knob is set according to refrigerator load. It is also recommended that the temperature be set lower during cold weather. 2. The refrigerator & freezer doors are tightly shut. 3. The sweat looks like condensation on the window of an air-conditioned room on a rainy day.
When refrigerator makes "unusual noise" like sizzling, ticking or humming:	Please note that these may be normal sounds that indicate that your ref is working properly: "Sizzling"-This indicates the refrigerant passing through the freezer compartment. "Ticking"-This indicates be the thermostat control is turning on and off. "Humming"-This is the sound of the working motor.
7. When there is ice formation on the inner back wall of the ref compartment (2 door models):	This is a natural characteristics of the cold wall design because the ref has its OWN cooling system. The ice melts away when the desired temperature is achieved. It is best to always set the temperature control knob properly to avoid excessive ice build-up. It is also important to defrost when needed.

If problem still occurs after checking all items above, please call our *Customer Care Hotlines:

 Trunkline:
 02 8 863 5555

 TOLL FREE:
 1800 10 888 8888

 Globe:
 +63 917 536 3030

 Smart:
 +63 947 996 2415

*Number are subject to the change without prior notice

Please prepare the following information to be relayed to the Customer Care Representative who will take your call:

- Customer ID No. (if already previously assigned one)
- Customer Name
- Address (House No., Block / Lot, Street, Subdivision, Barangay, Clty and Nearest Landmarks)
- Contact Nos. (Land line Nos. House & Office, Cellphone Nos.)
- Model & Serial No. of your refrigerator (found on the sticker inside ref)
- Dealer Branch (where the unit was purchased)
- Date of Purchase (according to sales invoice/receipt)
- Complaint or problem encountered

You may also scan the provided QR code to book a service




Scan QR code for service needs

You may also scan the provided QR code to book a service

7 Parts List

Here are the reasons why you trust our brand. Find out what makes us your choice.

7. PARTS LIST



No.	Description	CSD73SAi	CTD75MNi	CTD85MNi	СТD93МNі	CTD102MNi
1	Ice Tray	1	1	1	1	1
2	Freezer Door	1	-	-	-	-
3	E-Mask	1	-	-	-	-
4	Control Knob	1	1	1	1	1
5	Chill Tray	1	-	-	-	-
6	Drain Spout	1	-	-	-	-
7	Control Box	1	1	1	1	1
8	Ref Sliding Shelf	3	3	3	2	3
9	Bottle Shelf	-	-	-	1	1
10	Crisper Glass	1	1	1	1	1
11	Crisper Pan	1	1	1	1	1
12	Egg Shelf	1	1	1	1	1
13	Bottle Rack Small	3	2	2	-	2
14	Bottle Rack Large	1	1	1	2	1
15	Freezer Shelf	-	1	2	2	2
16	Freezer Bin	-	1	1	1	1
	Ice Scraper	1	1	1	1	1
	Drain Pan	Υ	Υ	Υ	Υ	Υ
	Leveller	Υ	Υ	Υ	Υ	Υ
	Hot Gas System	Y	Υ	Υ	Υ	Υ
Available Colors			N	lidnight Sapphii	re	
	Net Volume (Liters)	205	211	238	261	287
	Freezer Volume (Liters)	28	52	79.5	102	102
	Ref Volume (Liters)	177	158.5	158.5	159	185
Overall Height (mm)		1426	1485	1664	1600	1765
Overall Depth (mm)			562		585	
Overall Width (mm) Voltage / Cycle Defrosting System Semi-			519		5	40
				230 / 60		
		Semi-Auto		Mai	nual	



www.condura.com

Fill-up this warranty card completely and n date of purchase. This will activate your th that is VALID FOR NEGOSYO USE. Only from	nree (3) years warranty
MODEL NO.:	SERIAL NO.:
DEALER:	BRANCH:
DATE OF PURCHASE:	DEALER INVOICE NO.:
CUSTOMER NAME:	EMAIL ADDRESS:
ADDRESS:	
TELEPHONE NO.:	MOBILE NO.:
	and use by Concepcion Durables, Inc. (CDI) of the data above for Notice published in its website (www.condura.com), which is Card.

CONDURA

PRODUCT WARRANTY CERTIFICATE

IMPORTANT: PLEASE READ CAREFULLY

Concepcion Durables, Inc. (CDI) warrants the purchaser, that this CONDURA refrigerator will be free from defective material and workmanship, and agrees to repair, or at its discretion, replace any defective material with a new or equivalent part, through any of its Authorized Service Centers, only if found to be manufacturer's defect and in accordance with the terms of this warranty, subject to the following conditions:

1. WARRANTY PERIOD (from the date of original purchase)

CONDURA	WARRANTY
1 year	 INVERTER BOARD
2 years	 LED LAMP
3 years	 SYSTEM PARTS & LABOR (Refrigerant, Filter Drier, Condenser & Freezer Coil)
10 years	 COMPRESSOR (Motor only. Does NOT include System Parts & Labor
3 months	 PLASTIC PARTS (Freezer Door, Ref Door, Door Handle, Door Shelves, Rubber Gasket, Chill Tray)
O Warranty	 Crisper Glass, Line Cord

There will be corresponding charges for labor and replacement parts after the warranty period.

2. COVERAGE OF WARRANTY

The CONDURA warranty is also applied to refrigerators used for business and commercial purposes.

3. LIMITATIONS

This warranty is not transferable, valid only in the Philippines, and does not apply to damage(s) due to fire, improper use or abuse (punctured), force majeure (typhoon, flood, lightning, earthquake, etc.), use with voltages beyond the allowable range of 198V to 242V, or failure to follow operating instructions, provided in the manual, if the serial number is removed or defaced, or if the unit has been tampered with, altered or in any way repaired, serviced or worked on by anyone other than a duly authorized representative or Service Center, this warranty is cosidered null and void. Concepcion Durables, Inc. (CDI) offers this warranty as the only remedy available to the original purchaser for any defect, that may arise within the warranty period. Correction of defects shall be considered as complete fulfillment of liabilities and responsibilities of CDI to the original purchaser. In no event shall CDI be held liable for any damage or consequence that may arise as a result of using this CONDURA product.

MODEL NUMBER:	SERIAL NUMBER:

NOTE: Keep this warranty card together with your Original Sales Invoice / Official Receipt as proof of purchase. If the date of purchase cannot be proven, warranty shall be based on CDI's invoice to Dealer.

CONCEPCION DURABLES INCORPORATED CUSTOMER SERVICE DEPARTMENT


308 Sen. Gil. Puyat Avenue, Makati City Trunk Line: 02 8 863 5555

1800 10 888 8888 **TOLL FREE:**

0917 536 3030 (Globe) Mobile Nos.: 0947 996 2415 (Smart)

> PO BOX 211 COMMERCIAL CENTER MAKATI CITY







CUSTOMER SERVICE DEPARTMENT

GMA & LUZON Area

308 Sen. Gil Puyat Avenue, Makati City Address:

Trunk Line: 02 8 863 5555

TOLL FREE: 1800 10 888 8888

+63 917 536 3030 (Globe) "SMS Only" +63 947 996 2415 (Smart) "SMS Only" Mobile Number:

Covered Region/Areas: National Capital Region (NCR), Ilocos Region (Region I), Cordillera Administrative Region

(CAR), Central Luzon (Region III), CALABARZON (Region IV-A), MIMAROPA except Romblon

(Region IV-B), Bicol Region excépt Masbate (Region V)

Email Address: customercare@condura.com

CEBU Regional Office:

Dr. A Esperanza Building. A.C Cortes Ave. Mandaue City 032 328 1416 / 032 347 3380 Address:

Telefax No:

+63 947 996 2416 Mobile Number:

+63 921 222 0942 **TOLL FREE:** 1800 10 888 8888

Covered Region/Area: Masbate, Central Visayas (Region VII), Eastern Visayas (Region VIII)

ILOILO Regional Office:

109 Yulo Street, Brgy. Yulo-Arroyo, Iloilo City, Iloilo Address:

Telefax No: 033 336 1121 +63 947 996 2417 Mobile Number:

+63 999 925 5736 **TOLL FREE:** 1800 10 888 8888

Covered Region/Area: Romblon, Western Visayas (Region VI)

CAGAYAN DE ORO Regional Office:

Address: No. 102 CKY Center, Capistrano-Chavez Street, CDO City

088 881 0615 Telefax No:

Mobile Number: +63 947 996 2419 +63 939 253 5011

1800 10 888 8888

TOLL FREE: Covered Region/Area: Zamboanga Peninsula (Region IX), Northern Mindanao (Region X), Autonomous Region in Muslim Mindanao (ARMM) except Maguindanao, Agusan del Norte, Surigao del Norte

DAVAO Regional Office:

Address: 1C, Nand-Saling Building, Sobrecarey Street, Obrero, Davao City

082 291 7276 +63 947 996 2418 +63 922 294 1478 Telefax No: Mobile Number:

1800 10 888 8888 **TOLL FREE:**

Covered Region/Area: Davao Region (Region XI), SOCCSKSARGEN (Region XII), Agusan del Sur, Surigao del Sur, Maguindanao

*All contact information detailed above may change without prior notice.